



KM055

Rotation direction : from the end of shaft extended to see, the direction is in clockwise.

